H21A-EN-K01

SD Load OS

▪ Begin with a formatted Micro SD Card (HC and non HC both work) and a main battery charged to at least 30%

▪ Locate files flash.bin and *.mbn in the production folder.

▪ Download FLASH.bin and *.mbn into root of SD card

▪ Open battery compartment and unlock SD socket

▪ Install SD card

▪ Re-lock SD socket from within battery compartment

▪ Install battery and lock battery door.

▪ Hold [Right Scan] + [Camera] + [Volume Down] and press [Power]

▪ Wait for message 'DOWNLOAD OK' to appear at bottom of screen

▪ Use stylus to press reset button on left side of device

▪ Press power button or connect to external power to boot device
Windows Mobile will emit startup tones two times and on the second will appear the 'Tap the screen to begin' dialog.