

Batch Mode Commands

To put the OPN 2006 or PX-20 in batch mode, scan the **+MSTR+** barcode. Device will then be in batch mode and will continue to store the data until the transmit data barcode is scanned



To transmit the data and leave the device in batch mode, scan the **+MXMT+** barcode



To transmit the data and start scanning in real time mode, scan the **+MSTP+** barcode



To clear the temporary memorized data, scan the **+MCLR+** barcode

