

Menu labels for USB interface switching



DO NOT scan following labels by the scanners without USB interface. It causes troubles about serial communications.



Configuration is fully initialized by interface switching. Use custom default to save current configuration.

Scan following labels to switch USB interface.

Scanner's interface will be switched to the interface you scanned.

[Switch interface to USB-COM]



USB-COM

[Switch interface to USB-HID]



USB-HID

OPTICON