





SSI Commands

Use the following command barcodes to set the command mode for the MDL units.

ZZ		SET
U*		Activate SSI commands
U2		Activate Opticon commands
ZZ		End